

IT'S A HEAT WAVE!

What does that mean to you as an Authorized Lawrence Factor Dealer?

With record temperatures all across the United States there is a hidden danger to air station operators. Filter processing capacity is severely reduced when high temperatures are present. As you should be well aware, filter processing capacity is affected by a number of parameters. Pressure, temperature and flow rate are the governing factors on how long a filter should be kept in any given purification system to allow the safe production of compressed breathing air.

Lawrence Factor dealers should make their customers aware that due to the extremely high temperatures affecting most of the United States, that the importance of properly calculating filter life due to high temperatures is critically important. A 20 degree F. Rise in the temperature will cut a filters processing capacity nearly in half. Yes! You heard right a 50% reduction in filter life with just a 20 degree rise in temperature. A filter system that has a normal change schedule of every 20 hours now will have to change those same filters every 10 hours due to the extreme heat. Based on the current heat wave that is covering the majority of the United States, most areas are at least 20 degrees F. Hotter than their average yearly temperature. Have your customers been alerted to this hidden danger? Have your filter sales doubled? If not, you should notify your customers of this dangerous situation and help them become "Air Aware" and safe producers of compressed breathing air.

Most manufacturers rate filtration system processing capacity based on a given pressure at a given temperature. As in creative marketing this data varies from manufacturer to manufacturer. This can give a false illusion that some manufacturers systems will process more air, utilizing a lower inlet temperature, than another manufacturers system who uses a higher, more reasonable temperature in these system processing calculations. Be aware of creative marketing. If you purchase a compressor and they tell you the filter system will process 40,000 cubic feet of air you must be aware that is at a given temperature of 68 degrees F. Now if you are in the Caribbean where the temperature is 80 degrees F, that same system will only process approximately 26,000 cubic feet of air. If the temperature is 95 degrees F the system will now only process 18,200 cubic feet of air which will mean more frequent filter changes to insure safe breathing air. That is the same system at different operating temperatures resulting in a dramatic difference in how long the filter will last. So warn your customers and help them be "Air Aware" and safe system operators.

Here is a quick guide to temperature conversion calculations. First, you must understand what temperature the manufacturer of your system uses to

calculate published processing capacity.

If the manufacturer uses 68 °F. Then here is your calculation table.

- 50 °F multiply the system processing capacity by 1.81
- 68 °F multiply the system processing capacity by 1.00
- 80 °F multiply the system processing capacity by .65
- 86 °F multiply the system processing capacity by .58
- 95 °F. multiply the system processing capacity by .455
- 104 °F multiply the system processing capacity by .34

If the manufacturer uses 80 °F. Then here is your calculation table.

- 50 °F multiply the system processing capacity by 2.8
- 68 °F multiply the system processing capacity by 1.54
- 80 °F multiply the system processing capacity by 1.00
- 86 °F multiply the system processing capacity by .88
- 95 °F. multiply the system processing capacity by .70
- 104 °degrees F multiply the system processing capacity by .523

Inlet gas temperature; where is it measured from? This is very controversial. Some say it's at the inlet of the compressor and others say at the inlet of the chemical bed. For the sake of simplicity, we are using the air temperature as it enters the intake but for true accuracy, the manufacturers of the chemicals tell us to use the temperature as it enters the chemical filter bed. This is another story altogether.

The contents of this article are the property of Lawrence Factor, Inc. Any reproduction must not be published without the written permission of the author and/or Lawrence Factor, Inc. Copyright © All rights reserved.



4790 NW 157 Street, Miami Lakes, FL 33014 U.S.A.
Phone: (305) 430-0550 Fax: (305) 430-0864
Website: www.Lawrence-Factor.com